Standheizung freischalten bei 4 Zonen Klima

Beitrag von „TAltemeier“ vom 24. Januar 2012 um 16:01

> Zitat von tthom
>
> From factory this heater is used only after engine start, but its easy to make it work as a parking heater and activate timers menu in RNS.
> 1 In Hidden menu check option car/cardevicelist - Auxiliary Heater
> 2 set option Auxiliary Heater to 5 in car / carmenuoperation
> 3 set enabled bit 4 in byte 1 of 08-AutoHVAC module.
>
> Then turn off the ignition and start once again. A menu Aux Heater should appear in Climate screen of RNS. There you could setup a day, time and duration of heating. at fixed time you should see ventilation start, and even some smoke under the car
>
> Alles anzeigen

Sollte nach den Änderungen der Button "Standheizung" nicht sichtbar sein, hilft ein Neustart des Computers. Entweder Fahrzeug abstellen und warten - irgendwann fährt der ja von selbst herrunter oder alternativ
über **Phone-Climate-Nav-Traffic-Knopf in der Mitte** neustarten.

Je nachdem ob bei dem Fahzeug eine Frontscheibenheizung eingebaut ist oder nicht, erscheint der Knopf für die "Standh." in der Mitte oder ganz Rechts.